




## 96 Heavy Duty Floor Doo Closer Adjustment Instruction


## 1. Adjusment of Range of Closing Speed 1 & 2





2. Adjustment of Closing Speed & Activate Any Degree Hold-Open in Closing Speed 2





\*There is no function of Any Degree Hold-Open in Closing Speed 1. Please don't turn C clockwise to Max Level or the door will be not moveable.

		Max Level or the door will be not moveable.	
Defalut Setting of Closing Speed Range	Default Setting	Turn C Clockwise	Turn C Clockwise To Approximately MAX
Default Setting	Fast 180 Fast	Fast 180 Slow	Fast 180 90 Very Slow
Turn D Clockwise	Slow 180 90 Fast	Slow 180 Slow	Slow 180 90 Very Slow
Turn D Clockwise	Any Degree 180 Hold-open	Any Degree 180 Hold-open	Any Degree 180 Hold-open

